

GREEN MODE

Within Cross Point we believe that every product should be made with the environment in mind. Therefore our products are based on durable materials and low power consumption. To reduce the power consumption of our products to a minimum outside opening hours of your store, we have developed the Green Mode.

The Green Mode is available for the majority of our systems. All other products have been designed in such a way that power consumption is already reduced to a minimum, so the Green Mode will not affect these products.

In order to be able to use our Green Mode, a CrossCONNECT Access Point must be installed in your store. This Access Point triggers each connected product to enter or exit the Green Mode, based on one of the following available settings:

Normal Green Mode is activated and deactivated based on the week day with the widest opening hours

Strict Green Mode is activated and deactivated based on the opening hours of each individual day

Smart Green Mode is activated and deactivated based on detection of a visitor

Note: Cross Point visitor counting products must be installed in order to be able to use this setting

When the Green Mode is active, the electronic boards inside the antennas remain powered, but power consuming circuits of these boards are switched off. Detection of tags is disabled, but in Optima models visitors are still detected and counted.

We recommend using the Green Mode where possible. This will not only save you money, but also help to reduce the strain of our products on the environment. Not only for yourself or us, but also for our children.

